

Thank you for your Evil Controller purchase! We would like to begin by explaining the features included with this controller.

## 1 Re-mapping Ability

## 2 Toggle Ability

The Re-mapping ability allows you to relocate functions on your controller to the 'blank buttons'.

The Toggle feature allows you imitate a button being pressed and held, when it's actually just being tapped one time. This feature is helpful for many different games.

### BUTTON LEGEND



### LED LEGEND



Each quadrant will flash, stay lit, or flash then stay lit.


The LEDs will flash based on the amount of mods on:  
If 2 mod features are on, it will flash in sequences of 2.  
If 3 mod features are on, it will flash in sequences of 3.

Macro Mode must be entered in order to relocate the buttons to the 'blank' ones.

## STEP 1: MACRO MODE



PRESS and HOLD the back button (on the face of your controller near guide button) for 3 seconds.



After 3 seconds have passed, the 4th quadrant LED on the face of your controller will blink, indicating you are in Macro Mode.

## STEP 2: BLANK BUTTON MODE


Once you have entered Macro Mode, you can begin relocating the buttons. This step is when you decide whether you want to remap the function or toggle it.

To *Remap* the function, TAP the 'blank' button that you would like to assign a function to.



The 4th quadrant on the face of your controller should stop blinking and now be illuminated. This indicates that you have selected that button to assign a function to.

To *Toggle* the function, PRESS and HOLD the 'Blank' button for 3 seconds.



The 4th quadrant on the face of your controller should stay illuminated briefly and then flash. This indicates that you have selected that button to assign a toggle function to.



## STEP 3: ASSIGN FUNCTION

Now that we have selected the button we would like to assign a function to, we need to pick the function we want to relocate.

To *Remap* the function, TAP the button that you would like to relocate. To perform rapid remap function, tap button you're relocating twice.



The 4th quadrant on the face of your controller should start blinking again. This indicates that you are back in BLANK BUTTON mode, which means you successfully relocated the function to that blank button.

To assign more functions, repeat steps 2 and 3.

## STEP 4: TURNING MOD ON/OFF



To turn off the mod, Tap the back button. The 4th quadrant LED on the face of your controller will turn off.





## NOMAD FAQ

**Q: What is the toggle feature?**

A: The toggle feature allows you to imitate a button being pressed and held. Imagine if you needed to hold the A button down in a game while you push other buttons. It gets annoying holding the A button, so the toggle feature allows you to tap a button and imitate the button being held.

## General FAQ

**Q: My controller works when I get it, but eventually it starts to act up on me. Why is this?**

A: Your controller requires sufficient batteries to power the mod inside. Try replacing your batteries with BRAND NEW AAs and see if the issue is still present.

**Q: Can I use my rechargeable battery pack on my modded controller?**

A: Yes, BUT it is not recommended. These batteries hold very little power and over time their capacity is reduced, making it more susceptible to malfunctioning.

**Q: Does my controller have an included warranty?**

A: Yes, your controller has an included 30 day parts and labor. If any issues arise with the functionality of your mod, we will fix it at no extra cost.

**Q: Is my controller undetectable?**

A: Yes, your controller is 100% undetectable and legal.

**Q: How can I contact you if I have any issues?**

A: Feel free to contact us at: 1-877-880-EVIL (3845) or e-mail us at [info@evilcontrollers.com](mailto:info@evilcontrollers.com)

**Q: If I'm happy with my product, how can I spread the GOOD word of EVIL?**

A: Please leave a review for your product on our website and tell your friends!