



Welcome to the Evil Family!

You are now the proud owner of an Evil Controller!

The Master Mod® V3.1 is our ultimate modded controller and features all of the mods that we offer for the PlayStation 3®. The Master Mod® comes with 9 different features compatible with Call of Duty®, Battlefield®, Destiny®, and much much more.

Our Adjustable Rapid Fire feature is compatible with all major first-person shooters and allows you to fine-tune the rate of fire in your favorite titles. For the latest game updates, visit evilcontrollers.com.

To maximize your potential, be sure to read the instructions fully before operating the Master Mod®.

BEFORE YOU GET STARTED:

Set your Button Layout!

Our controller supports all 10 Call of Duty button layouts. To change your controller's button layout with your in-game selected button layout, follow these instructions:

Hold down the Mod switch, then hold triangle to change the button layout. The Player 4 LED will blink slowly to indicate which button layout you have selected. Keep holding both buttons to cycle through all of the available layouts.

Hold the Mod Button + Hold Triangle – Change Button Layout

<u>Hold Triangle Button</u>	<u>To Change Button Layouts:</u>
Layout 1:	Default
Layout 2:	Tactical
Layout 3:	Lefty
Layout 4:	Nom4d*
Layout 5:	Nom4d Tactical (Charlie)*
Layout 6:	DefaultAit
Layout 7:	Tactical Flipped
Layout 8:	Lefty Flipped
Layout 9:	Nom4d Flipped*
Layout 10:	Nom4d Tac Flip*

*Limited mod support in Nom4d layouts

Super-Fast Rapid Fire Group Switching:

Change your rapid fire immediately by following these instructions:

Hold down the Mod switch then tap any one of the following buttons to switch to that Rapid Fire. The mod switches Rapid Fire group immediately, and the Player 4 LED flashes quickly to acknowledge. When any Rapid Fire mode is enabled, Player 4 LED stays illuminated.

Hold the Mod Button + Hold the Button Below - Change Rapid Fire Group

<u>Press This Button</u>	<u>To Change to This Rapid Fire Group</u>	<u>What does this Rapid Fire Group do for me?</u>
Fire Weapon	Single-trigger Rapid Fire	Turns single-fire guns into full-auto guns
ADS (Scope)	Dual-trigger Rapid Fire	Turns single-fire guns into full-auto guns
Throw Tactical	Zombie Auto-Aim	Enables auto-aim when in Zombie arcade mode
D-Pad Up	Auto Burst (Jitter Rapid Fire)	Increase the firing rate of most guns (patched in MW3)
D-Pad Left	Akimbo Rapid Fire	Unload your semi-auto Akimbo pistols in the blink of an eye
D-Pad Right	Burst Rapid Fire	Fires most guns with 2, 3, 4 or 5-round bursts
D-Pad Down	All Rapid Fire turns off	Quickly turns off all Rapid Fire!

SUPER-FAST MOD TOGGLING:

Hold down the Mod Switch, then tap any one of the following buttons to toggle that feature on or off. The mod toggles that special mode on/off immediately, and the Player 3 LED flashes quickly to acknowledge. When any special mode is enabled, Player 3 LED stays illuminated.

Hold the Mod Button + Hold the Button Below - Toggle Mod On/Off

<u>Press This Button</u>	<u>To Toggle This Mode</u>	<u>What does this Mod do for me?</u>
Melee Attack	Quick Scope	Tap your ADS button to shoot a single quickscope
Hold Breath	Auto Scope	When scoping, holds your breath automatically
Reload	Fast Reload	Reload your gun faster (patched in MW3)
Crouch/Prone	Drop Shot	Drop the ground when you fire your weapon
Throw Lethal	Turbo Melee	Knife faster than usual (requires Semtex)
Jump(X)	All Special Mods	Quickly turns off

	Turned Off	all special features!
--	------------	-----------------------

CHANGING MODES WITHIN EACH GROUP

In addition to Fast Rapid Fire Switching and Mod toggling, the Rapid Fire Groups and Special Features can also be customized. Hold down the Mod Switch, then hold down any one of the following buttons to customize your mod. Player 4 LED will blink slowly to indicate which mode you are changing to. Our Master Mod® will always remember your selections, even when you power off your controller.

Hold Mod Switch + Hold Fire Weapon Button – Scroll through Rapid Fire Speeds

<u>Hold Fire Weapon Button</u>	<u>Rapid Fire Speeds to Scroll Through</u>
Mode 1:	Modern Warfare 3 - All other pistols
Mode 2:	Modern Warfare 3 - MK14
Mode 3:	Modern Warfare 3- P99 and Five-Seven
Mode 4:	Black Ops
Mode 5:	MW2
Mode 6:	MW2 w/doubletap
Mode 7:	Halo Series
Mode 8:	GTA4
Mode 9:	Rainbow Six Series
Mode 10:	World at War●

*Special mode only for use with World at War

Hold Mod Switch + Hold Throw Tactical – Change Zombie Modes Available

<u>Hold Throw Tactical</u>	<u>To Change Zombie Modes Available:</u>
Mode 1:	Zombie auto-aim, no Rapid Fire
Mode 2:	Zombie auto-aim, plus Rapid Fire

Hold Mod Switch + Hold D-Pad Up – Change Auto Burst Modes

<u>Hold D-Pad Up</u>	<u>To Change Auto Burst Modes:</u>
Mode 1:	Auto Burst (Tri, Tri) stays on always
Mode 2:	When Active, Auto Burst (Tri, Tri) turns off
Mode 3:	Auto Burst (Sq, Tri, Tri) stays on always
Mode 4:	When Active, AutoBurst (Sq, Tri, Tri) turns off

Hold Mod Switch + Hold D-Pad Left – Change Akimbo Modes

<u>Hold D-Pad Left</u>	<u>To Change Akimbo Modes</u>
Mode 1:	When Active, Rapid Fire is right-side only
Mode 2:	When Active, Akimbo mode turns off
Mode 3:	Akimbo stays on always

Hold Mod Switch + Hold D-Pad Right – Change Burst Firing Rate

<u>Hold D-Pad Right</u>	<u>To Change Burst Firing Rate</u>
Mode 1:	2-round burst
Mode 2:	3-round burst
Mode 3:	4-round burst
Mode 4:	5-round burst

Hold Mod Switch + Hold Reload – Change Fast Reload Timing

<u>Hold Reload</u>	<u>To Switch the Fast Reload timing:</u>
Mode 1:	Gun 1- Timing 33
Mode 2:	Gun 2 -Timing 34
Mode 3:	Gun 3- Timing 36
Mode 4:	Gun 4- Timing 42
Mode 5:	Gun 5- Timing 53
Mode 6:	Gun 6- Timing 54
Mode 7:	Gun 7- Timing 56
Mode 8:	Gun 8- Timing 63
Mode 9:	Gun 9- Timing 213
Mode 10:	Gun 10- Timing 214

ADJUSTABLE RAPID FIRE PROGRAMMING

If you need to adjust your rate of fire beyond the 10 pre-set rapid fire speeds, you can create your own! Reprogram your Rapid Fire mode to any speed from 5 shots-per-second up to 99 shots-per-second. Rapid Fire speed is programmed by individually setting the tens digit, the ones digit, and the decimal digit.

For example, if the speed is 16.2 shots per second. "1" is the tens digit, "6" is the ones digit, and "2" is the decimal digit.

Any time an LED or LED's flash very quickly, this means one of your numbers is set to "0". Otherwise it will slowly blink the number. When in Adjustable Rapid Fire programming mode, hold L1 to decrease speed, R1 to increase speed, or tap the Mod Switch to save the setting. To enter into Adjustable Rapid Fire programming mode, hold Mod switch, left bumper, right bumper, then pull the right trigger. The controller will let you know that it has entered programming mode by alternating the Player 3 and 4 LED's a few times. The controller will then flash the tens digit to you on the Player 4 LED. Adjust the speed and then tap the Mod Switch. The controller will then flash the ones digit to you on the Player 3 LED. Adjust the speed and then tap the Mod Switch.

The controller will then flash the decimal digit to you on the Player 3 and Player 4 LEDs. Adjust the speed and then tap the Mod Switch. The controller will let you know that it saved your new speed by alternating the Player 3 and 4 LED's a few times.

ADJUSTABLE RAPID FIRE PROGRAMMING COMMANDS

Hold Mod Switch + Hold L1 + Hold R1 + Tap R2 = Enter Adjustable Rapid Fire Mode

Hold L1 = Decrease Speed

Hold R1 = Increase Speed

Mod Switch = Save Setting

CUSTOMIZE FAST RELOAD SPEED PROGRAMMING

Just like Adjustable Rapid Fire, you can adjust your Fast Reload delay to work with virtually any gun in the Call of Duty series. Fast reload delays are programmed by individually setting the hundreds digit, the tens digit, and the ones digit. For example, if the reload delay is 105 units, "1" is the hundreds digit, "0" is the tens digit, and "5" is the ones digit. Any time an LED or LED's flash very quickly, this means one of your numbers is set to "0". Otherwise it will slowly blink the number. When you enter Fast Reload adjustment programming mode, hold L1 to decrease speed, R1 to increase speed, or tap the mod switch to save the setting. To enter into Adjustable Fast Reload speed programming mode, hold the mod switch, left bumper, right bumper, then tap the Square button. The controller will let you know that it has entered programming mode by alternating the Player 3 and 4 LED's a few times. The controller will then flash the hundreds digit to you on the Player 3 and Player 4 LEDs. Adjust the speed and then tap the mod switch. The controller will then flash the tens digit to you on the Player 4 LED. Adjust the speed and then tap the mod switch. The controller will then flash the ones digit to you on the Player 3 LED. Adjust the speed and then tap the mod switch. The controller will let you know that it saved your new speed by alternating the Player 3 and 4 LED's a few times.

ADJUSTABLE FAST RELOAD PROGRAMMING COMMANDS

Hold Mod Switch + Hold L1 + Hold R1 + Tap Square = Enter Fast Reload Programming Mode

Hold L1 = Decrease Speed

Hold R1 = Increase Speed

Mod Switch = Save Setting